



SYNC

OPEN-EAR AUDIO &
GROUP COMMUNICATION




POCKET GUIDE EN

TABLE OF CONTENTS

Getting Started	3-4
Cardo Connect App	5
General	6
Music	7
Phone Call	8
Cellular Intercom	9

ADVANCED FEATURES

Shimano Connectivity	10
Default Settings	11
Customizing Shimano Connectivit	12



Press & Hold



Number of Taps

Getting Started




On / Off

First time: automatic pairing ON




L



R




If needed: start new pairing



R



LED Red & Blue






Download



Register and Activate



Choose Language




Update Software






Volume Up



Volume Down




Voice Assistant



Siri



*Google
Assistant*



Auto On/Off

You can activate this option via your **Cardo Connect App > Settings**




Play / Stop

R



Next Track

R



Previous Track

R





Answer

Press any button to
answer the phone call




L



R



End Call




L







Grouping



Intercom ON/OFF



Mute / Unmute Microphone





Shimano Pairing

Overview of default settings

Di2


DIGITAL INTEGRATED INTELLIGENCE

- 1) Update your Di2 firmware.
- 2) Set button(s) on Shimano Di2 shifters to a D-Fly channel with the Shimano E-Tube App.
- 3) Press any button on shifter for pairing.



SHIMANO E-BIKE SYSTEMS

- 1) Update your firmware.
- 2) Set button(s) on Shimano EBIKE systems to a D-Fly channel with the Shimano E-Tube App.
- 3) Switch on the bike for pairing.



1. Do not pair when other bike is around
2. Put your bike not further than 1 m



LED Red & Blue





Overview of default settings

9:41

←

Shimano connectivity

D-FLY channel 1

Short press:

Mic mute / unmute

Double press:

Cycling information

Long press:

Voice assistance

D-FLY channel 2

Short press:

Unable/ disable group co...

Double press:

Music on / off

Long press:

Answer / end call

D-FLY channel 3

Short press:

Volume up

Double press:

Next track

Long press:

+ Add action

D-FLY channel 4

Short press:

Volume down

Double press:


Previous track

Long press:


+ Add action




Open Settings menu



Open Shimano Connectivity



Change commands





STAY IN TOUCH



Cardo Support

.....

Follow Cardo

